


MX24 /230V / 12V POWER

Users Guide / Information Data sheet



Switch on for 230V
before you can use
below

Wall heater

Hot water heater

Wall 3 pin sockets



Danger

Disconnect the
mains supply before
removing this cover

WARNING — ELECTRICAL SHOCK HAZARD

Craft is equipped with a d.c. to a.c. power inverter.
To avoid serious injury or death from electrical shock:
Disconnect a.c. shore power and d.c. battery power to inverter

Switch off Mains fuse
box and disconnect
shore power lead
before changing any
fuses 230 or 12v
behind panel


MX24 /230V / 12V POWER

Users Guide / Information Data sheet




MX24 /230V / 12V POWER

Users Guide / Information Data sheet



12v Battery SWITCH / Under sink in kitchen cupboard.




MX24 /230V / 12V POWER

Users Guide / Information Data sheet

Main RCD shore power SWITCH / front righthand side of doors.

Switch off if working on electrics AC/DC or 12v



Please Familiarise yourself with all the above.

If in doubt, please contact owner.